

Configuration GT3000

A) Setup:

1. Start the GT3000 → the GT3000 will reset himself automatically.
2. Hold the [SELECT] Button → hit 3 times the [ITEM] Button then Press [START].
3. Now you entering the "H10 Size Adjust" Menu.

H10 Size Adjust

B) Changing Settings:

1. Press the [UP] Button until you see "H100 Set Port" on the Display.
2. Press the [START] Button - it appears "DATA" in the secondline.
3. Use the [UP] and [DOWN] buttons until "EDGER" appears
4. with the button [SELECT] switch to "USB".
5. Use the [UP] and [DOWN] buttons until "HIT" appears, then press the [SELECT] Button.
6. Press [RESET] to delete the secondline.
7. Press the [UP] Button until "H103 Set Protocol" appears in the Display.
8. Press the [START] button - it appears "Data" in the Secondline.
9. Use the [UP] and [DOWN] buttons until "HOYA" appears, then hit [START].
10. Switch with the [SELECT] button to "USB".
11. Use the [UP] and [DOWN] buttons until "HOYA" appears, then press [START].
12. Turn the GT3000 Off and On.
13. Switching from Protocol "HOYA" to "OMA" is possible when you hold down the [ITEM] button and pressing 5 times the [UP] button, then press [START].

H100 Set Port

H100 Set Port
Data ?????

H100 Set Port
Data EDGER

H100 Set Port
USB ?????

H100 Set Port
USB HIT

H100 Set Port

H103 Set Protocol

H103 Set Protocol
Data OMA

H103 Set Protocol
Data Hoya

H103 Set Protocol
USB OMA

H103 Set Protocol
USB HOYA

H103 Set Protocol
Data HOYA

H103 Set Protocol
USB HOYA